

Aaa flashcards

chapter 10



**ASSIGN
BUSTER**

When shifting gears with a manual transmission, the clutch must be: always be pushed all the way to the floor

When shifting gears, you should: be able to shift without looking at the pedals or shift lever.

ONAAA FLASHCARDS CHAPTER 10 SPECIFICALLY FOR YOU FOR ONLY \$13.90/PAGE Order Now

The friction point of the clutch is the point at which the clutch pedal is: let up part way to a point where the engine starts to move the vehicle

When shifting from first to second, the correct procedure is: clutch pedal down, shift, accelerator pedal up

First gear in a vehicle with a manual transmission should be used for speeds up to approximately: 15 mph

fourth and fifth gears are generally engaged at speeds over: 40 - 50 mph

When you park and leave a manual-shift vehicle, it is best to set the parking brake and shift to: both a and c are correct (first gear and reverse)

"Riding the clutch" will: rapidly wear the clutch's surface

if you do not operate the clutch properly you could: all the above are correct (stall your engine, experience bumpy jerks, have vehicle jerk forward when you attempt to accelerate)

You are driving a manual-shift vehicle in third gear at 30 mph and you plan to turn right at the next intersection. The street has a slight uphill grade. It is best to: downshift to second gear and slow before the turn.